

DAVES 4.6 QUICK INSTALLATION GUIDE

1. Connect all source A/V cables to DAVES 4.6 main unit (controller).
2. Connect CAT5 cable from main unit zone output to DAVES-Rx zone receiving units. On the DAVES-Rx units, it is the lower RS-45 connector.
3. Connect CAT5 cable from upper RS-45 connector on DAVES-Rx unit to DAVES-KP keypad/amplifier.
4. Connect speaker wires from the left and right speakers to the DAVES-KP. Screw terminals. Observe the polarity of the speaker wires.
5. First, power all the DAVES-Rx zone units. The DAVES-KP should light up.
6. After all the DAVES-Rx units are powered up, apply power to the DAVES 4.6 main unit.
7. Power-up all the sources and test the system.
8. To initialize the DAVES-KP, hit the Mute first, then bring the volume all the way down and all the way up. Then, return the volume to normal level.
9. To turn-off the zones, just hit the Mute button. It puts the system in stand-by mode.